# Let's get started.

Need help? Scan the QR code for video tutorials and user guide.




link.gl-inet.com/rm1pe-userguide-support



GL-RM1PE / Comet PoE Remote KVM

## PRODUCT INTERFACE DESCRIPTION



D IN

For capturing video signal output from the controlled device.

## **SUPPORT**

## **Technical Support**

- For more detailed and updated instructions, please visit our website https://docs.gl-inet.com/kvm/en/user\_guide/
- For further questions, contact us via these methods:
  - Email: support@gl-inet.com
  - Discord: link.gl-inet.com/website-discord-support
  - Reddit: link.gl-inet.com/website-reddit-support
  - Forum: forum.gl-inet.com

## **TROUBLESHOOTING**



## Repair / Reset

Press and hold the Reset button for 8 seconds to restore factory settings.



### Remote Mouse Cursor Misalignment


 If the mouse cursor on the controlled computer isn't appearing in the same position on your screen, adjust the computer's display resolution to one of the supported options listed below.

**60FPS Support:** 2560x1440, 1920x1200, 1920x1080, 1600x1200, 1440x900, 1360x768, 1280x1024, 1280x800, 1280x720, 1024x768, 800x600.

30FPS Support: 3840x2160.


## **SETTING UP**









Connect the GL-RM1PE device to the PoE Switch with a network cable.






Connect the controlled host and the GL-RM1PE device with an HD cable.








Connect the controlled host and the GL-RM1PE device with the USB cable.







Visit https://www.gl-inet.com/app-rm/ to download and install the application on the Device A. Follow the on-screen instructions to register an account and bind your GL-RM1PE.



## WARRANTY

- We provide two-year limited warranty for routers and 3-month limited warranty for accessories
- Extra warranty may apply according to the local law in which the product purchase took place.
- Any damage to the device caused by not following the instructions will render this warranty null and void
- Any damage to the device caused by modifying the PCBA, components or case will render this warranty null and void.
- Issues caused by the use of third-party firmware may not get official support from us.
- Any damage to the device caused by inappropriate use, e.g. inappropriate voltage input, high temperature, dropping in the water or on the ground will render this warranty null and void.
- Pictures on the instructions are only for reference. We reserve the right to change or modify. these materials without further notice

This device complies with Part 15 of the ECC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation

#### Declaration of conformity

Hereby, GL TECHNOLOGIES (HONG KONG) LIMITED declares that this product type [Remote KVM, GL-RM1PE] is in compliance with the essential requirements and other relevant provisions of Directive 2014/30/EU and 2011/65/EU. The full text of the EU declaration of conformity is available at the following internet address: https://www.al-inet.com/products/certificate.

#### Hong Kong Office

GL Technologies (Hong Kong) Limited Unit 601, Building 5W, Hong Kong Science Park. Shatin, N.T., Hong Kong

#### Shenzhen Office

Shenzhen Guanglianzhitong Tech Co., Ltd. Room 305 - 306. Skyworth Digital Building. Shiyan Street. Baoan District, Shenzhen, China, 518000 (+86-0755-86606126)









