

Let's get started.

Need help? Scan the QR code for video tutorials and user guide.



link.gl-inet.com/mt5000-userguide-support

GL·iNet


**GL-MT5000 / Brume 3
Security Gateway**

SETTING UP

1

Connect via Ethernet Port


Plug the cable connecting to the gateway into the WAN port, and plug the cable connecting to your computer into the LAN port.



2

Power On

Plug in power cable.




3

Set Up Gateway

Visit <http://192.168.8.1> in your browser to set up your gateway; start by choosing your preferred language.



SUPPORT



Repair / Reset

If you cannot access the web-based setup page or cannot connect to the gateway, you can press the **Reset** button:

- Press and hold for **3 seconds** and then release to repair your network. The light will turn blue and flash slowly until your network recovers.
- Press and hold for **10 seconds**, and then release to reset the gateway to factory settings. The light will turn blue and flash rapidly. All data will be cleared when the light becomes solid blue.



link.gl-inet.com/mt5000-userguide-support

Technical Support

- For more detailed and updated instructions, please visit our website link.gl-inet.com/mt5000-userguide-support
- For further questions, contact us via these methods:
 - Email: support@gl-inet.com
 - Discord: link.gl-inet.com/website-discord-support
 - Reddit: link.gl-inet.com/website-reddit-support
 - Forum: link.gl-inet.com/website-forum-support

WARRANTY

- We provide a two-year limited warranty for gateways and a three-month limited warranty for accessories. Additional warranty coverage may apply according to the local laws where the product was purchased.
- Highly recommend using the included **5V/3A** power adapter.
- Any damage to the gateway caused by not following the instructions will render this warranty null and void.
- Any damage to the gateway caused by modifying the PCBA, components, or case will also render this warranty null and void.
- Issues caused by the use of third-party firmware may not be eligible for official support.
- Any damage to the gateway caused by improper use, e.g. incorrect voltage input, high temperature, dropping the device into water or onto the ground, will render this warranty null and void.
- Pictures on the instructions are only for reference. We reserve the right to change or modify these materials without further notice.

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
 - (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAN ICES-3(B) NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Hereby, GL Technologies (Hong Kong) Limited declares that this product is in compliance with the essential requirements and other relevant provisions of EMC directive 2014/30/EU, LVD directive 2014/35/EU. A copy of the EC Declaration of Conformity (DoC) is available online at <https://www.glinet.com/products/certificate>.

Hong Kong Office

GL Technologies (Hong Kong) Limited
Unit 601, Building 5W, Hong Kong Science Park,
Shatin, N.T., Hong Kong

Shenzhen Office

Shenzhen Guanglianzhong Tech Co., Ltd.
Room 305 - 306, Skyworth Digital Building, Shiyan Street,
Baoan District, Shenzhen, China, 518000
(+86-0755-86606126)

